

s product is permanent, washable and colorfast when properly alled Used by the parment Industry; Follow directions for

the fabric Lay heated from on transfer, press FIRMLY

Allow to cool completely before removing paper, If transfer will not release or is not woaked into fabric, replace paper and

NOT re-iron directly over the surface of an applied transfer if pased prints with this paper, waxed paper or aluminum foil:

Iron - On Transfer

Places Read - DIRECTIONS - Important

plied. Used by the garment industry. Follow directions for

Not recommended for hylon or garments to be dry cleaned. Transfer must be ironed on a herd surface (folded bath towel on a firm table is preferable to ironing board). Lay out garment. the labric Lay heated iron on transfer; press FIRMLY Iron repeat this step several times until entire area has been

Allow to cool completely before removing paper. If transfer will not release or is not soaked into fabric, replace paper and

Save Ulia special paper until garment has been washed several times. If transfer was not properly applied repeat steps 2 & 3.

NOT re-iron directly over the surface of an applied transfer. If rment must be pressed, or additional transfers applied, cover

Fabric Prints 1976 *6839

Please Read - DIRECTIONS - Important

This product is permanent, washable and colorfast when properly applied. Used by the garment industry, Follow directions for professional results!

- Not recommended for nylon or garments to be dry cleaned,
- a firm table is preferable to ironing board). Lay out garment the labric Lay heated iron on transfer press FIRMLY downward 10 to 15 seconds. If transfer is larger than surface of
- Allow to cool completely petere removing paper, if transfer will not release or is not soaked into fabric, replace paper and repeat steps 2 & 3
- Save this special paper until garment has been washed several times. If transfer was not properly applied repeat steps 2 & 3.

© Fabric Prints 1976 "6839

Iron - On Transfer

Please Read - DIRECTIONS - Important

This product is permanent, washable and colorfast when properly applied. Used by the garment industry; Follow directions for professional results!

- 1. Not recommended for nylon or garments to be dry cleaned.
- 2. Transfer must be ironed on a hard surface (folded bathtowel on a firm table is preferable to ironing board). Lay out garment. Smooth out wrinkles Preheat iron to between wool and cotton setting. Position transfer on garment compound side toward the fabric. Lay heated iron on transfer; press FIRMLY downward 10 to 15 seconds. If transfer is larger than surface of iron repeat this step several times until entire area has been covered. Do not use circular motion.
- 3. Allow to cool completely before removing paper, if transfer will not release or is not soaked into fabric, replace paper and repeat steps 2 & 3.
- 4. Save this special paper until garment has been washed several times. If transfer was not properly applied repeat steps 2 & 3.

DO NOT re-iron directly over the surface of an applied transfer. If garment must be pressed, or additional transfers applied, cover exposed prints with this paper, waxed paper or aluminum foll.

© Fabric Prints 1976 *6839

Please Read - DIRECTIONS - Important

This product is permanent, washable and colorfast when properly applied. Used by the garment industry; Follow directions for professional results!

- Not recommended for pylon or garments to be dry cleaned.
- Transfer must be ironed on a hard surface (folded bath towel on a firm table is preferable to troning board). Lay out garment. Smooth out wrinkles. Preheat iron to between wool and cotton setting Position transfer on garment compound side toward the fabric. Lay heated iron on transfer press FIRMLY downward 10 to 15 seconds. If transfer is larger than surface of iron repeat this step several times until entire area has been covered Do not use circular motion.
- 3. Allow to cool completely before removing paper. If transfer will not release or is not soaked into fabric, replace paper and repeat steps 2 & 3
- 4. Save this special paper until garment has been washed several times if transfer was not properly applied repeat steps 2 & 3.

garment must be pressed, or additional transfers applied, cover exposed prints with this paper, waxed paper or aluminum foil.

©Fabric Prints 1976 *6839

Iron - On Transfer

Please Read - DIRECTIONS - Important

This product is permanent, washable and colorfast when properly applied. Used by the garment industry, Follow directions for professional results!

- 1. Not recommended for nylon or garments to be dry cleaned.
- 2. Transfer must be ironed on a hard surface (folded bath towel on a firm table is preferable to ironing board). Lay out garment Smooth out wrinkles. Preheat iron to between wool and cotton setting. Position transfer on garment compound side toward the fabric. Lay heated iron on transfer; press FIRMLY downward 10 to 15 seconds. If transfer is larger than surface of iron repeat this step several times until entire area has been covered Do not use circular motion.
- 3. Allow to cool completely before removing paper. If transfer will not release or is not soaked into fabric, replace paper and repeat steps 2 & 3
- 4. Save this special paper until garment has been washed several times. If transfer was not properly applied repeat steps 2 & 3.

DO NOT re-iron directly over the surface of an applied transfer. If garment must be pressed, or additional transfers applied, cover exposed prints with this paper, waxed paper or aluminum toll,

©Fabric Prints 1976 *6839

Please Read - DIRECTIONS - Importan

This product is permanent, washable and colorfast who applied. Used by the garment industry; Follow dir professional results!

- 1. Not recommended for hylon or garments to be dr Transfer must be ironed on a hard surface (folded ba a firm table is preferable to ironing board). Lay or
- Smooth out wrinkles. Preheat iron to between wool setting. Position transfer on garment compound s the labric. Lay healed iron on transfer; press downward 10 to 15 seconds. If transfer is larger that iron repeat this step several times until entire are covered. Do not use circular motion.
- Allow to cool completely before removing paper. If t not release or is not soaked into fabric, replace repeat steps 2 & 3. Save this special paper until garment has been was
- times. If transfer was not properly applied repeat s

DO NOT re-iron directly over the surface of an applied garment must be pressed, or additional transfers app exposed prints with this paper, waxed paper or alumin

©Fabric Prints 1976 "6839

DO1-

Iron - On Transfer

Please Read - DIRECTIONS - Importan

This product is permanent, washable and colorfast wh applied Used by the garment industry; Follow dir professional results

- 1. Not recommended for nylon or garments to be dr
- Transfer must be ironed on a hard surface (folded by a firm table is preferable to ironing board). Lay of Smooth out wrinkles. Preheat iron to between wool setting. Position transfer on garment compound to the fabric. Lay heated iron on transfer; press downward 10 to 15 seconds. If transfer is larger tha iron repeat this step several times until entire are covered. Do not use circular motion,
- 3. Allow to cool completely before removing paper. If not release or is not soaked into fabric, replace repeat steps 2 & 3.
- Save this special paper until garment has been was times. If transfer was not properly applied repeat a

DO NOT re-iron directly over the surface of an applied garment must be pressed, or additional transfers app exposed prints with this paper, waxed paper or alumi

©Fabric Prints 1976 *6839